




License Options



Continued on next pages

License Options	Basic	Activated	Standard	Full
Fully working demo mode for all devices and modules	✓	✓	✓	✓
Task Scheduler, External Text Sources, TXT, RSS, XML and JSON parsers	✓	✓	✓	✓
Embedded Demo RDS encoder, RDS Spy decoder	✓	✓	✓	✓
Maximum number of active External Text Outputs	1	3	6	32
Dynamic Text Loop maximum lines	3	6	40	40
Unidirectional communication option, Text Conditions	✗	✓	✓	✓
Control of PIRA P132, P164, P232, P232U, P332 and Readbest RDS Encoders	✗	✓	✓	✓
Control of MicroRDS/MRDS1322, PIRA32, UECP, Lite ASCII and DAB+ Encoders	✗	✗	3	128
Text publishing on the web, save text to disk, send text in special format	✗	✗	✓	✓
Add-ons	✗	✗	✓	✓
License type	FREE	FREE *)	\$59.00 LIFETIME	\$290.00 LIFETIME

Notes:

* The Activation is made automatically upon bidirectional communication with any of these RDS encoders: P132, P164, P232, P232U, P332, READBEST. The Activation is permanent in the context of installation.

** Get the Standard or Full license online at <https://pira.cz/rds/magicrds/buy/>.

Frequently Asked Questions

What is the paid license time duration?

The license is life-time and includes all future updates.

Can I install the Magic RDS 4 on a PC that does not have internet access?

Yes, you can. The target PC does not need to be online during the operation or installation. One of the advantages of our system is that it can run safely in a separate computer network.

I'm running multiple instances of the Magic RDS 4 on my PC. Is this still covered by a single license?

Yes, the license is tied to the operating system, regardless of how many instances of the application you're running.

For the Standard license, you're not allowed to operate the application on different PC machines (physical or virtual) at the same time. The Full license can be operated on up to 5 PC machines.


I moved all my broadcast software to a new PC. Do I need to buy a new license?

No, you don't need to buy another. The license is life-time. Using your existing **User ID**, which you received by email upon purchase, you can simply generate new **License key** online for your new installation.

The old license key remains valid for a certain period of time, to allow smooth transition to the new installation.

Where to find the Installation ID?

In the Magic RDS main menu, select Help - License Manager:



Right-click on the Installation ID string and select Copy to clipboard. Then paste the string into the field on the 'Get License Key' internet page: <https://pira.cz/rds/magicrds/key/>

Still having questions?
Contact us or visit our
Technical forum at
<https://pira.cz/forum/>